



FOX S.r.l. Via Romagna, 6 - 20090 OPERA (MI) - ITALY  
Tel. +39.02.57600033 - 6543 - Fax +39.02.57600176  
www.fox.it - fox@foxsrl.com



## **CALIBRATION PROCEDURE OF ED5**

### **FOLLOW THE INSTRUCTION POINT TO POINT**

- Verify to have **zero pressure** and alimentate the instrument
- Push **T3** to visualize "SET"
- Push **T2** to visualize "CAL"
- Push **T2** and **T3** at the same time to visualize "CAL" (beginning scale)
- Push **T2** to confirm, it will appear CAL
- Push **T1** and **T3** at the same time to visualize "CAL" (end scale)
- Carry the pressure in the system at the maximum value of the scale of the transducer
- Push **T1** to confirm
- Push **T4** repeatedly to exit the programming and visualize the system pressure value on the display

**VERIFY THAT THE PRESSURE VISUALIZED IS THE REAL PRESSURE OF THE SYSTEM**

**THE INSTRUMENT IS READY TO USE**

